

10481

**07-13 JEEP
WRANGLER
UNLIMITED
2 DOOR**



10481

**07-13 JEEP
WRANGLER
UNLIMITED
2 DOOR**

UPPER CLASS HOOD/DOOR HINGE ACCENTS

Tools Required:

Alcohol
Clean Rag

Hardware / Parts List:

4 Stainless Door Hinge Accents
2 Stainless Hood Hinge Accents

Step 1

Read and understand all instructions before attempting the install of this grille. Be sure that the package of hardware matches the hardware list as listed above. Next, test fit the T-REX grille to the vehicles factory openings. You are now ready for the install:

Step 2

Clean the area of the door and hood hinges using alcohol and a clean rag. Test fit the hinge accent to the vehicle. Unpeel the backing of the accent piece. Making sure the accent is straight; apply to the hinge. With the accent piece straight; apply pressure to the accent till adhesion has been accomplished. Repeat on all hinges.

Thank you for purchasing your T-Rex billet grille. 5/30/08