

07-13 JEEP WRANGLER SAHARA EDITION

Sahara Trim Kit

TOOLS REQUIRED: Alcohol/Clean Rag PARTS LIST: 1 T1 Series Sahara Trim Kit - 2 Pc.

Step 1

Clean the area where the Trim Kit will be installed with alcohol and a clean rag. Test fit the trim kit. Remove the plastic backing on the adhesive on the back of the Trim Kit.

Step 2

Position the Trim Kit on top of the factory Sahara Logo as in the picture below. Press on the Trim Plate to ensure the adhesive backing adheres to the vehicle body.

